

INSTALLATION INSTRUCTIONS SECURITY LOCKBOX SET #020 AND #031

Please read and fill out the enclosed warranty registration card to activate your warranty.

PARTS CHECKLIST



TOOLS NEEDED

- Electric drill
- 3/8" Drill bit
- Marker or pencil
- Knife
- ½" Socket and ratchet
- ½" Wrench
- ¼" Wrench or Socket and Ratchet
- Silicone sealant (Recommended)

PLEASE READ ALL INSTRUCTIONS THOROUGHLY BEFORE STARTING INSTALLATION.

This section applies to Part # 020 only


- 1. Bolt your speaker to the Tuffy box by placing the speaker cloth between the speaker and the box and securing with fasteners provided with the speaker.
- 2. Route speaker wires through either the hole in the bottom of the box or the hole on the side of the box.
- 3. If you did not route the wires through the hole in the side of the box, plug the hole with the 5/16" plug provided.
- 4. Connect speaker wires to speaker in accordance to the speaker installation manual.

- 5. Install rubber seal on lid and check lock operation.
- 6. Place your Tuffy box in the vehicle on the wheel well, make sure placement of box does not interfere with the movement of the seat or convertible top.
- 7. Using a marker or pencil, mark any (3) spots through the 3/8" mounting holes in the box.

WARNING!

Make sure that there is nothing under the vehicle that will be damaged by the drill bit when drilling.

- 8. Remove the box. Cut the carpet at the (4) marked holes. Using a 3/8" drill bit, drill out the (4) marked spots in the floor.
- 9. It is recommended to use silicone sealant in any holes drilled in the vehicle to prevent rusting.
- 10. Bolt the Tuffy box to the vehicle using (4)5/16x1-1/4" Bolts, (4) 5/16" Nuts and (8) 5/16" Washers. For security purposes it is best to insert the bolts from the underside of the vehicle up.
- 11. Part # 020 only Slide the divider down and then over the screws inserted in your Tuffy box. Secure the divider to the box using the (3) #4 washers and (3) #4 nuts provided. (See FIGURE 1)
- 12. Repeat steps for installation of box on the other side of the vehicle.



Call (970) 564-1762 for Technical Support